

Switches & Pilot Devices

Signaling Lights

Relays & Sockets

Timers

Contactors

Terminal Blocks

Circuit Breakers

Selection Guide

| Appearance | Product Series | Mounting Hole | Contact Rating | Contact Mounting | Function | Page |
|-------------------------------------------------------------------------------------|----------------|---------------------------|----------------|-------------------|----------------------------------------------------------------------------|------------------------------------------------------------------|
|  | AP | ø8mm, ø10mm, ø12mm, ø16mm | N/A | N/A | Pilot light | 488 |
|  | A8 | ø8mm | 1A | Unibody | Pushbutton, Pilot Light | 492 |
|  | X6 | ø16mm | 5A | Unibody | E-Stop | 497 |
|  | XA | | 5A | Removable/Unibody | E-Stop | 501 |
|  | A6 | | 1A | Unibody | Pushbutton, Pilot Light, Selector Switch, Key Switch, Stop Switch | www.IDEC.com/switches |
|  | LB | ø16mm | 3A | Removable | Pushbutton, Pilot Light, Selector Switch, Key Switch, Lever Switch, Buzzer | 508 |
|  | L6 | | 5A | Removable | Pushbutton, Pilot Light, Selector Switch, Key Switch, Stop Switch, Buzzer | 527 |
|  | XW | | 5A | Removable | E-Stop | 569 |
|  | AP22M | ø22mm | N/A | Unibody | Pilot Lights | 575 |
|  | CW | | 10A | Removable | Pushbutton, Pilot light, selector switch, key selector | 578 |
|  | HW | | 10A | Removable | Pushbutton, Pilot Light, Selector Switch, Key Switch, E-Stop, Mono-Lever | 600 |

Selection Guide con't

| Appearance | Product Series | Mounting Hole | Contact Rating | Contact Mounting | Function | Page |
|-------------------------------------------------------------------------------------|----------------|--------------------|----------------|------------------|-------------------------------------------------------------------|------------------------------------------------------------------|
|  | TW | ø22mm | 10A | Removable | Pushbutton, Pilot Light, Selector Switch, Key Switch, Stop Switch | 661 |
|  | FB | | N/A | N/A | Enclosures | 702 |
|  | XN | ø30mm | 5A | Removable | E-Stop | 704 |
|  | TWTD | | 10A | Removable | Pushbutton, Pilot Light, Selector Switch, Key Switch, Stop Switch | 710 |
|  | CS | | 10A | Unibody | Cam Switch | 753 |
|  | ARN | ø25mm, □ 25 x 25mm | 10A | Removable | MonoLever | 760 |
|  | LW Flush | | 5A | Removable | Pushbutton, Pilot Light, Selector Switch, Key Switch | www.IDEC.com/switches |

Switches & Pilot Devices

Signaling Lights

Relays & Sockets

Timers

Contactors

Terminal Blocks

Circuit Breakers